

Audio Feast


Premium Audio Components
Music City USA Nashville TN

AK DAC Direct output Transformer:

Input connection:

- 0 AOUTRN or AOUTLN on AKM DAC chip
- 1 AOUTRP or AOUTLP on AKDAC chip
- CT not used

The Core Ground wire needs to be soldered to the shield case



Output connection:

0	GND for Unbalanced,	Negative for Balanced
1	Hot for Unbalanced,	Positive for Balanced
CT	not used for Unbalanced,	GND for Balanced



